


# Connector at left A-post (bottom rail harness)

White connector C1 (53-pin)  
Instrument panel harness - sill harness



all models		
1	Tail lights	(BN-W)
2	Tail lights	(R)
3	Brake light, left	(Y-R)
4	Brake light, right	(Y)
5	Backup (reversing) lights	(SB)
6	Number plate lights	(W)
7	Turn signal, left rear	(GN)
8	Turn signal, right rear	(BL-GN)
9	Fuel level sensor/primer pump (pump)	(GR-W)
10	Heated rear window	(Y)
11	Sensor, speedometer -	(BN-W)
12	Sensor, speedometer +	(GN-W)
13	Door switch, pre-routed interior lighting	(W-SB)
14	Towing hook pos. 10	(BL-GN)
15	Rear foglights	(GR)
16	Fuel level sensor/primer pump (pump)	(BN)
17	Fuel level sensor/primer pump (pump)	(P)
18	Extra brake light	(Y-SB)
19	Tailgate wiper	(OR)
20	Tailgate wiper	(Y-W)
21	Power antenna pos. 3	(GN-GR)
22	-	
23	-	
24	Ground connector, left A-post	(BN-GR)
25	Towing hook pos. 9	(W-SB)
26	Towing hook pos. 7	(W)
27	Towing hook pos. 5	(GR)
28	Towing hook pos. 6	(Y-BN)
29	Door-open warning light, left rear Interior lighting Trunk light Power antenna pos. 1	(GN-R)
30	Interior lighting	(BN-SB)
31	Connector, tailgate/trunk (anti-theft alarm)	(BN-OR)
32	-	
33	Loudspeaker rear parcel shelf right side +	(GN-BN)
34	Loudspeaker rear parcel shelf right side -	(GN)
35	Loudspeaker left rear door + Loudspeaker rear parcel shelf left side +	(Y-W)
36	Loudspeaker left rear door - Loudspeaker rear parcel shelf left side -	(W)
37	-	
38	Central locking, rear door Central locking, tailgate/trunk	(R-W)
39	-	
40	-	
41	Central locking rear door Central locking, tailgate/trunk	(BL-R)
42	-	
43	-	
44	-	
45	-	
46	-	
47	-	
48	-	
49	-	
50	Power window lift motor, rear door	(GN)
51	Power window lift motor, rear door	(GR)
52	-	
53	Power window lift motor, rear door ON/OFF	(P)