

Instrument panel lamps

10/74	Warning lamp, exhaust gas temperature	10/82	Warning lamp, ABS	10/89	Warning lamp, rear foglights
10/75	Warning lamp, turbodiesel charge pressure	10/83	Warning lamp, parking brake	10/90	Warning lamp, washer fluid level
10/76	Warning lamp, diesel preheating	10/84	Warning lamp, brake warning	10/91	Service indicator
10/77	Warning lamp, SRS	10/85	Warning lamp, high beam	10/92	Warning lamp, trailer
10/78	Warning lamp, seat belts	10/86	Warning lamp, oil pressure	10/93	Warning lamp,
10/79	Warning lamp, overdrive (aut.)/Gearshift indicator	10/87	Warning lamp, charging		Malfunction indicator lamp (MIL.)
10/80	Warning lamp, overdrive (man.)	10/88	Warning lamp, bulb malfunction indicator	10/94	Warning lamp, right turn signal
				10/95	Warning lamp, left turn signal

- 1 Right turn signal (BL-GN)
- 2 Reference ground, ground connector, left A-post (BN-GR)
- 3, 4 -
- 5 Instrument and control lighting (W)
- 6 Ignition coil socket 1 or generator socket W (R-W)
- 7 Engine coolant temp. (ECT) sensor (Y-SB)
- 8 Engine coolant temp. (ECT) sensor (Y-W)

- 1 Supply 30+ (GN-R)
- 2 Left turn signal (GN)
- 3 Fuel level sensor (GR-W)
- 4 Fuel level sensor (BN)
- 5 Rheostat adjustment pos. 2 (GN-BN)
- 6,7,8 -
- 9 Control module, (MFI) fuel system pos. 22, control module (DI) ignition system pos. 3 (BN-W)
- 10 -
- 11 Relay, exhaust temp. sensor (W)
- 13 Washer fluid level sensor (BL-W/R-SB)
- 14 Foglight switch pos. 5 (GR)
- 15 Bulb malfunction indicator pos. 1 (BL-Y)
- 16 Generator D+ (R)
- 17 Oil pressure sensor (SB)
- 18 High beam (BL-W)

- 1 Sensor, speedometer (GN-W)
- 2 Sensor, speedometer (BN-W)
- 3 Ground connection rail in el. dist. unit (BN)
- 4 Supply 15+ (BL-R)

Digital socket, cruise control (GN-OR),
control module ECC (Y), O/D relay (aut.)/control
module (MF1) fuel system (VO-W/VO-W)

- 1 Instrument and control lighting (BL)
- 2 Brake fluid level sensor (VO)
- 3 Parking brake switch (BN)
- 4 ABS (GN)
- 5 -
- 6 Seat belt reminder (Y)
- 7 Seat belt reminder (BL-GN)
- 8 Relay, glow plug system pos. 1 (OR)
- 9 -
- 10 Pressure sensor, turbodiesel (Y-R)
- 11 -
- 12 Crash sensor SRS pos. 3 (BN-SB)

