


Heated driver's/passenger's seat, normal output



Thermostat activated at +14 C
and deactivated at +26 C

Temperature above +26 C: heater
elements switched OFF by thermostat

Ignition ON and passenger's
seat also ON