

Manual Climate Control (MCC)

One precondition for the climate unit to work is that the fan must be ON, at any speed (signal from 4/40B:6 to 4/40A:7).

Fan at speed 1. Climate unit ON.

