


Connectors in engine compartment at left suspension tower



B 230 F, REX-I

D24/D24TIC

Connector C50 (8-pin)

1	Pos. 2, connector C137 at right suspension tower (4-pin)	(BL-R)
2	Ground, control module REX-I (DI), pos. 20	(BN)
	Ground, power amplifier/ignition coil REX-I (DI), pos. A	
3	Pos. 3, connector C137 at right suspension tower (4-pin)	(BL-SB)
4	Pos. 4, connector C137 at right suspension tower (4-pin)	(GN)
5	Control module Regina (MFI) pos. 25, via pos. 2, connector C55 at right suspension tower	(Y)
6	Knock sensor (KS) pos. 1	(GN)
7	Knock sensor (KS) pos. 2	(SB)
8	Pos. 1, connector C137 at right suspension tower (4-pin)	(BN-SB)

Connector C51 (8-pin)

1	Engine coolant temperature (ECT) sensor pos. 1	(Y-W)
2	Oil pressure sensor	(SB)
3	Ground, power amplifier/ignition coil REX-I pos. B	(SB)
4	Generator D+	(R)
5	Starter motor 50	(BL-GN)
6	Throttle position (TP) switch pos. 1	(OR)
	Pos. 8, connector C54 at right suspension tower	
7	Engine coolant temperature (ECT) sensor fuel/ignition (MFI/DI) system pos. 2	(R-SB)
8	Engine coolant temperature (ECT) sensor pos. 2	(Y-SB)

Connector C51 (8-pin)

1	Engine coolant temperature (ECT) sensor pos. 1	(Y-W)
2	Oil pressure sensor	(SB)
	Fuel valve	
3	Timer relay, exhaust gas recirculation (EGR) pos. 4	(BL)
	Idle air control (IAC) switch, EGR	
4	Generator D+	(R)
5	Starter motor 50	(BL-GN)
6	Engine coolant temperature (ECT) sensor diesel	(BN)
7	Generator W	(R-W)
8	Engine coolant temperature (ECT) sensor pos. 2	(Y-SB)

Connector C117 (2-pin)

1	Pressure sensor, turbodiesel (D24TIC)	(Y-R)
2	-	