

List of components

1/1	Battery	3/59	Beam width control
2/2	Relay, front foglights	3/66	Idle air control (IAC) control, EGR
2/3	Regulator DIM-DIP	3/70	Rheostat setting
2/4	Intermittent relay, windshield wipers	3/78	Lock unit, tailgate
2/5	Relay, seat belt reminder/ignition key warning	4/1	Overheating protector, driver's seat
2/6	Bypass relay 15I	4/2	Overheating protector, passenger's seat
2/7	Central locking relay	4/3	Control module, cruise control
2/8	Overdrive relay	4/4	Rheostat
2/10	Power unit ECC	4/5	Safety circuit, SRS (airbag)
2/11	Relay, engine cooling fan	4/6	Control module, ECC
2/12	Relay, radio interference suppression	4/9	Sensor module, SRS (airbag)
2/13	Relay, fuel injection (MFI)	4/10	Control module EZ-K (DI) system
2/14	Relay, glowplug mechanism	4/15	Power amplifier, EZ-K (DI) system
2/15	Relay, exhaust gas temperature sensor	4/16	Control module ABS
2/16	Tailgate intermittent wiper relay	4/23	Control module LH-jetronic 2.4 (MFI) system
2/23	Relay, fuel injection	4/25	Control module Regina (MFI) system
2/34	Relay, front foglights	4/26	Power amplifier/ignition coil REX-I (DI) system
2/36	Headlight flasher	4/29	Control module driver's seat
2/37	Headlight relay	4/40	A/C controls, MCC
2/38	Timer relay, exhaust gas recirculation (EGR)	4/42	Control module REX-I (DI) system
2/45	Relay, P-shift lock	4/43	Heater controls
2/50	Bypass relay, high beam	5/1	Combined instrument
3/1	Ignition lock	5/3	Ambient temperature sensor
3/2	Light switch	6/1	Windshield wiper motor
3/4	Cruise control operation	6/2	Washer motor, front
3/5	Switch, turn signal/high-low beam	6/3	Right headlight wiper motor
3/6	Switch, hazard warning flashers	6/4	Left headlight wiper motor
3/7	Foglight switch	6/5	Central locking motor, passenger's side front
3/8-1	Switch, heated rear window	6/6	Central locking motor, passenger's side rear
3/8-2	Switch with timer relay, heated rear window/door mirrors	6/7	Central locking motor, driver's side rear
3/9	Brake light switch	6/8	Central locking motor, tailgate
3/10	Backup (reversing) light switch	6/9	Window lift motor driver's door
3/12	Switch, windshield wash/wipe	6/10	Window lift motor driver's side rear
3/13	Switch, tailgate wash/wipe	6/11	Window lift motor passenger's side front
3/14	Switch, lock button	6/12	Window lift motor passenger's side rear
3/15	Power window switch, driver's door for driver's door	6/13	Power door mirror, driver's side
3/16	Power window switch, driver's door for driver's side rear door	6/14	Power door mirror, passenger's side
3/17	Power window switch, driver's door for passenger's side front	6/15	Motor, power sunroof
3/18	Power window switch, driver's door for passenger's side rear	6/16	Motor, driver's seat backrest
3/19	Power window switch, driver's side rear	6/17	Motor, up-down, front edge of driver's seat
3/20	Power window switch, passenger's side front	6/18	Motor, up-down, rear edge of driver's seat
3/21	Power window switch, passenger's side rear	6/19	Motor, fore-aft, driver's seat
3/22	Switch for rear power window lifts	6/24	Vacuum pump, cruise control
3/23	Switch for power door mirror, driver's side	6/25	Starter motor
3/24	Switch for power door mirror, passenger's side	6/26	Generator
3/25	Switch for power sunroof	6/27	Servo motor, throttle control
3/26	Operating module, driver's seat	6/28	Cabin fan motor
3/27	Operating module, passenger's seat	6/29	Engine cooling fan
3/28	Switch for heated driver's seat	6/30	Washer motor, tailgate
3/29	Switch for heated passenger's seat	6/31	Fuel pump
3/31	Door switch, driver's door	6/32	Tailgate wiper motor
3/32	Door switch, passenger's side front	6/33-1	Fuel level sensor/primer pump
3/33	Door switch, driver's side rear	6/33-2	Fuel level sensor/pump
3/34	Door switch, passenger's side rear	6/34	Power antenna
3/35	Door switch, tailgate (5-door estate)	6/35	Parking heater
3/36	Switch, glove compartment	6/36	Central locking motor, driver's side front
3/37	Horn contacts	6/38	Actuator, left
3/38	Switch, brake pedal	6/39	Actuator, right
3/39	Switch, clutch pedal	7/4	Brake fluid level sensor
3/40	Start inhibit switch, automatic transmission	7/5	Washer fluid level sensor
3/42-1	Switch on transmission	7/6	Oil pressure sensor
3/42-2	Oil pressure sensor, kick-down valve	7/7	Engine coolant temperature (ECT) sensor
3/43	Switch in gear lever	7/9	Engine coolant temperature (ECT) sensor, ECC
3/44	Seat belt lock, driver's seat	7/10	Cabin temperature sensor
3/47	Parking brake switch	7/11	Ambient temperature sensor
3/50	Throttle position (TP) switch	7/12	Solar sensor
3/52	Switch for power antenna	7/14	Thermostat, engine cooling fan
		7/15	Heated oxygen sensor (HO2S)
		7/16	Engine coolant temperature (ECT) sensor, fuel/ignition (MFI/DI) system