

7/17	Mass air flow (MAF) sensor	10/45	Right parking/tail light
7/24	Knock sensor (KS)	10/46	Right rear foglight
7/25	Engine speed (RPM) sensor	10/47	Bulb, right rear turn signal
7/26	Pressure sensor, EGR	10/48	Right backup (reversing) light
7/28	Engine coolant temperature (ECT) sensor, diesel	10/50	Left brake light
7/30	Pressure sensor for charge pressure, turbodiesel	10/51	Left parking light, rear
7/31	Sensor, ABS left front	10/52	Left parking/tail light
7/32	Sensor, ABS right front	10/53	Left rear foglight
7/33	Sensor, vehicle speed (VSS) and ABS	10/54	Bulb, left rear turn signal
7/34	Thermoelement, three-way catalytic converter (TWC)	10/55	Left backup (reversing) light
7/37	Temperature sensor, EGR	10/64	Right high beam
7/38	Low-speed pressure sensor, engine cooling fan	10/65	Right extra high beam
7/40	High-speed pressure sensor, engine cooling fan	10/66	Right low beam
7/41	High-pressure sensor, A/C	10/68	Left high beam
7/43	Thermostat, driver's seat	10/69	Left extra high beam
7/44	Thermostat, passenger's seat	10/70	Left low beam
7/47	PTC-resistor, air pre-heating	10/72	Ashtray lighting, front
7/50	Pressure sensor, intake manifold	10/74	Indicator light, exhaust gas temperature
7/52	Temperature sensor, intake air	10/75	Indicator light, charge pressure, turbodiesel
7/53	Low-pressure sensor, A/C	10/76	Indicator light, diesel preheating
7/69	Ambient temperature sensor	10/77	Indicator light, SRS (airbag)
7/75	Bulb malfunction indicator	10/78	Indicator light, seat belt
8/1	Operating solenoid, overdrive	10/79	Indicator light, overdrive (auto.)/Gear selection indicator
8/2	Solenoids, ECC	10/80	Indicator light, overdrive (man.)
8/3	Solenoid coupling, A/C	10/82	Indicator light, ABS
8/5	Idle air control (IAC) valve	10/83	Indicator light, parking brake
8/6-9	Injection valves	10/84	Indicator light, brake warning
8/13	Fuel valve, diesel	10/85	Indicator light, high beam
8/15	Hydraulic unit, ABS	10/86	Indicator light, oil pressure
8/17	Converter, EGR	10/87	Indicator light, charge
8/24	3-way valve, EGR	10/88	Indicator light, bulb failure
8/30	Steering wheel module, SRS (airbag)	10/89	Indicator light, rear foglights
8/33	Igniter for left seat belt tensioner	10/90	Indicator light, washer fluid level
8/34	Igniter for right seat belt tensioner	10/91	Service indicator
8/36	Solenoid P-shift lock	10/92	Indicator light, trailer
8/42	Solenoid, pulsed secondary air injection (PAIR)	10/93	Indicator light, malfunction indicator lamp (MIL)
9/1	Cigar lighter	10/94	Indicator light, right turn signal
9/2	Heated rear window	10/95	Indicator light, left turn signal
9/3	Heater element, driver's seat backrest	10/96	Instrument lighting
9/4	Heater element, passenger's seat backrest	10/103	Switch lighting, heated rear window/door mirrors
9/5	Heater element, driver's seat cushion	10/104	Switch lighting
9/6	Heater element, passenger's seat cushion	10/114	Vanity mirror lighting, passenger's side
		10/115	Vanity mirror lighting, driver's side
10/5	Left front foglight	11/1-26	Fuses
10/6	Right front foglight	11/41	Fuse, combined instrument
10/11	Left front parking light	15/1	Positive terminal
10/12	Right front parking light	15/2	30-rail in el. distribution unit
10/13	Left front turn signal	15/9	Fuse-protected 15-rail in el. distribution unit
10/14	Right front turn signal	16/1	Radio
10/15	Left turn signal repeater (not USA/CDN)	16/2	Amplifier
10/16	Right turn signal repeater (not USA/CDN)	16/3	Loudspeaker, right front door
10/19	Extra brake light	16/4	Loudspeaker, left front door
10/20	Left number plate light	16/5	Loudspeaker, right rear door
10/21	Right number plate light	16/6	Loudspeaker, left rear door
10/22	Roof light	16/7	Loudspeaker, instrument panel, right side
10/24	Trunk light	16/8	Loudspeaker, instrument panel, left side
10/25	Roof light, load area (5-door)	16/9	Antenna
10/29	Glove compartment light	16/10	Horn 1
10/30	Door-open warning light, driver's door	16/11	Horn 2
10/31	Door-open warning light, front passenger's side	16/15	CD-autochanger
10/32	Door-open warning light, rear driver's side	16/17	Loudspeaker, rear parcel shelf, left side/left D-post
10/33	Door-open warning light, rear passenger's side	16/18	Loudspeaker, rear parcel shelf, right side/right D-post
10/36	Control panel lighting		
10/38	Ashtray lighting, rear		
10/39	Switch lighting, seat heater		
10/40	Gear selector lighting		
10/43	Right brake light		
10/44	Right parking light, rear		

The component list continues on the next page