

17/1	Service data link connector for starter's motor operation	C40	Connector, at passenger's seat, 4-pin
17/11	OBID data link connector	C41	Connector, under driver's seat, 6-pin
17/14	Data link connector for diagnosis of power seat	C42	Connector, under driver's seat, 2-pin
		C50	Connector, 8-pin
18/1	Bridge connector 1		Left wheel housing harness - Engine harness
18/2	Bridge connector 2	C51	Connector, 8-pin
			Left wheel housing harness - Engine harness
19/1	Engine coolant temperature (ECT) gauge	C54	Connector, 8-pin
19/2	Rev. counter (RPM gauge)		Right wheel housing harness - Engine harness
19/3	Speedometer	C55	Connector, 8-pin
19/4	Clock		Right wheel housing harness - Engine harness
19/5	Fuel gauge	C62	Connector, at windshield wiper motor, 4-pin
		C63	Connector, at left headlight, 3-pin
20/1	Ignition coil	C64	Connector, at right headlight, 3-pin
20/2	Distributor	C65	Connector, driver's door, 6-pin
20/3-6	Spark plugs	C66	Connector, passenger's door, 6-pin
20/9	Glowplugs	C72	Connector, driver's door, 2-pin
20/15	Series resistance	C73	Connector, passenger's door, 2-pin
20/18	Cabin fan resistor	C74	Connector, rear door driver's side, 2-pin
		C75	Connector, rear door passenger's side, 2-pin
31/1	Ground connector right front wing	C76	Connector, right A-post, 2-pin
31/2	Ground connector left front wing	C79	Connector, driver's door, 4-pin
31/3	Ground connector body (ground connection, battery-body)	C84	Connector, driver's door, 2-pin
31/4	Ground connector engine (ground connection, battery-engine)	C85	Connector, rear door driver's side, 2-pin
31/5	Ground connector for heated rear window (4-door)	C86	Connector, passenger's door, 2-pin
31/6	Ground connector left A-post	C87	Connector, rear door passenger's side, 2-pin
31/9	Ground connector at parking brake lever	C88	Connector, at switch, 5-pin
31/10	Ground connector right A-post	C89	Connector, at sunroof motor, 2-pin
31/11	Ground connector left tail light	C91	Connector, at el. dist. unit, 2-pin
31/12	Ground connector right tail light	C92	Connector, behind steering wheel, 2-pin
31/13	Ground connector in load area	C93	Connector, left rear wheel housing, 4-pin
31/16	Ground connector at windshield wiper motor	C98	Connector, at power antenna, 4-pin
31/17	Ground connector at power sunroof motor	C100	Connector, left wheel housing, 2-pin
31/26	Ground connector, generator	C101	Connector, right wheel housing, 2-pin
31/28	Ground connector at overdrive solenoid	C102	Connector, at el. dist. unit, 2-pin
31/31	Ground connection rail in el. distribution unit	C105	Connector on bridge connector 1, 2-pin
31/32	Ground connector on engine (power ground)	C111	Connector, at thermoelement, 2-pin
31/33	Ground connector on engine (signal ground)	C117	Connector, 2-pin
31/60	Ground connector on engine (diesel)		Left wheel housing harness - Engine harness
31/63	Ground connector at steering column bracket	C121	Coupling reel, steering wheel, SRS (airbag)
31/64	Ground connector engine cooling fan	C123	Connector to bridge connector 2, 2-pin
		C132	Connector, 8-pin
C1	Connector, 53-pin		Left wheel housing harness - Engine harness
	Instrument panel harness - Door sill harness	C137	Connector, 4-pin
C2	Connector, 53-pin		Right wheel housing harness - Engine harness
	Instrument panel harness - Left wheel housing harness	C139	Connector, at gear selector, 4-pin
C3	Connector, 53-pin	C143	Connector, at A-post passenger's side, 24-pin
	Instrument panel harness - Right wheel housing harness	C144	Connector, at A-post driver's side, 24-pin
C5	Connector, left A-post, 2-pin	C149	Connector, at B-post passenger's side, 11-pin
C6	Connector, at el. dist. unit, 4-pin	C150	Connector, at B-post driver's side, 11-pin
C7	Connector, at steering column, 8-pin	C154	Connector, 3-pin or 1-pin
C9	Connector, at centre console, 10-pin		Right wheel housing harness - engine cooling fan harness
C11	Connector, at el. dist. unit, 4-pin	C155	Connector, left A-post, 8-pin
C12	Connector, at el. dist. unit, 2-pin	C156	Connector, at firewall, 3-pin
C14	Connector, at el. dist. unit, 2-pin	C157	Connector, at el. dist. unit, 4-pin
C15	Connector, left A-post, 4-pin	C158	Connector, at driver's seat, 4-pin
C19	Connector, at instrument panel, 2-pin	C160	Connector, at instrument panel, 6-pin
C20	Connector, under gear lever carrier, 1-pin or 2-pin	C161	Connector, at firewall, 1-pin
C21	Connector, left B-post, 4-pin	C162	Connector, left B-post, 2-pin
C22	Connector, at tailgate, 6-pin (5-door)	C163	Connector, at firewall, 2-pin (diesel)
C23	Connector, at tailgate, 2-pin (5-door)	C166	Connector, at el. dist. unit, 8-pin
C24	Connector, at extra brake light, 2-pin	C300	Connector, at firewall, 4-pin
C25	Connector, tailgate, 2-pin, (5-door)		(for heated oxygen sensor (HO2S))
C27	Connector, tailgate, 1-pin, (5-door)	C301	Connector, at instrument panel for vanity mirror, passenger's side
C29	Connector, at driver's seat, 4-pin	C302	Connector, at instrument panel for vanity mirror, driver's side
C31	Connector, at passenger's seat, 2-pin		
C32	Connector, at driver's seat, 2-pin	D1	Connector, at instrument panel, 4-pin
C33	Connector, under driver's seat, 2-pin	D2	Connector, alarm, 8-pin at steering column
C34	Connector, under passenger's seat, 2-pin	D3	Connector, alarm, 4-pin at steering column
C36	Connector, under passenger's seat, 2-pin	D4	Connector, alarm, 2-pin in engine compartment, left front
C37	Connector, under driver's seat, 2-pin	D5	Connector, towing hook, 10-pin (not USA/CDN)
C39	Connector, at driver's seat, 4-pin	D7	Connector, ambient temperature sensor, 6-pin