

Contents

How to use the wiring diagrams	2	Group 37	
Electrical distribution unit, fuses	4	On-board diagnosis (OBD)	98
Fuses	5	Pre-routed wiring for anti-theft alarm	100
Ignition lock and relay location in engine compartment	6	Pre-routed wiring for towing hook	102
Relay location, electrical dist. unit	7		
Wiring harnesses	8		
Connectors	9		
Ground connections	20		
Group 23			
LH-jetronic 2.4 multiport fuel injection system (MFI)			
(B 200 F/G, B 230 F/FB/FD/G)	22		
LH-jetronic 2.4 multiport fuel injection system (MFI)			
(B 200 FT, B 230 FT/GT)	24		
Regina multiport fuel injection system (MFI) (B 230 F)	26		
Group 26			
Engine cooling fan	28		
Group 27			
Cruise control	30		
Cruise control, function (schematic presentation)	32		
Group 28			
EZ 116 K Distributor ignition (DI) system			
(B 200 F/G, B 230 F/FB/FD/G)	34		
EZ 116 K Distributor ignition (DI) system (B 200 FT, B 230 FT/GT)	36		
REX-1 Distributor ignition (DI) system (B 230 F)	38		
Group 32			
Power supply	40		
Group 33			
Starter system	42		
Diesel preheating, overload protector and EGR (D 24 TIC)	44		
Group 35			
High and low beam	46		
High and low beam, Nordic region, Netherlands, Belgium	48		
High and low beam, Great Britain	50		
Reduced intensity low beam (DIM-DIP) Great Britain	52		
High and low beam, USA	54		
High and low beam, Canada	56		
Beam width control	58		
Parking lights, tail lights and number plate lights	60		
Parking lights, tail lights and number plate lights USA, Canada	62		
Brake lights	64		
Brake lights, USA, Canada	66		
Backup (reversing) lights	68		
Glove compartment and vanity mirror lighting	70		
Interior lighting	72		
Trunk light	74		
Instrument and control panel lights	76		
Foglights	78		
Foglights, Japan, Saudi Arabia, Taiwan and Overseas	80		
Foglights, USA, Canada	82		
Rear foglights, USA, Canada	84		
Group 36			
Turn signals and hazard warning flashers	86		
Horn	88		
Headlight wash/wipe	90		
Windshield wash/wipe	92		
Tailgate wash/wipe	94		
Cigar lighter	96		
Group 37			
On-board diagnosis (OBD)	98		
Pre-routed wiring for anti-theft alarm	100		
Pre-routed wiring for towing hook	102		
Group 38			
Bulb malfunction indicator	104		
Bulb malfunction indicator for cars with extra brake light	106		
Bulb malfunction indicator with brake monitor	108		
Seat belt reminder	110		
Seat belt reminder with ignition key warning, USA, Canada, Korea	112		
Combined instrument	114		
Speedometer and tripmeter	116		
Ambient temperature gauge	118		
Group 39			
Radio connections, 4-door	120		
Radio connections, 5-door	122		
Radio connections, 4-door (Radio with integrated amplifier)	124		
Radio connections, 5-door (Radio with integrated amplifier)	126		
Group 43			
M 46 Overdrive	128		
AW 70/70/72 Overdrive with kickdown inhibitor AW 71/72	130		
P-shift lock, automatic transmission	132		
Group 59			
ABS Brake system	134		
Group 83			
Power window lifts	136		
Central locking	138		
Power sunroof	140		
Group 84			
Heated rear window	142		
Heated rear window and door mirrors with timer relay	144		
Power door mirrors	146		
Group 85			
Heated driver's/passenger's seat, normal output	148		
Heated driver's/passenger's seat, high output	150		
Power seat	152		
Power seat with memory	154		
Group 87			
Cabin fan, standard heater	156		
Manual Climate Control (MCC)	158		
Electronic Climate Control (ECC)	160		
Exhaust temperature sensor (Japan)	162		
Group 88			
SRS Supplemental Restraint System (airbag)	164		
SRS Supplemental Restraint System (airbag) USA, Canada	166		
Feedback	168		
List of components (foldout)	at the end of the book		
Alphabetical index	at end of book		
Order no. TP 3904032 (UK)	Order no. TP 3904202 (USA/CDN)		
Supersedes TP 3904031	Supersedes TP 3904201		

We reserve the right to make alterations to specification