


Ignition lock and relay location in engine bay



Ignition lock

Inputs

30: two leads from battery

Outputs


Key position:

-	Key withdrawn
0	Off
I	Radio
II	Drive
III	Start

Voltage at connection:

P
S,P
X,S,P
X,15R,15L,S
15R,50,S

Relay location in engine compartment



- 2/11* Relay, engine cooling fan (B 200 F/G, B 230 F/FB/FD/G)
- 2/11** Relay, engine cooling fan (B 200 FT, B 230 FT/GT)
- 2/12* Relay, interference suppression (B 200 F/G, B 230 F/FB/FD/G)
- 2/12** Relay, interference suppression (B 200 FT, B 230 FT/GT)
- 2/14 Relay, glow plug (D 24 TIC)
- 2/38 Timer relay, exhaust feedback EGR (D 24 TIC)