



# Location of relays



Relays in electrical distribution unit

- |   |  |   |   |
|---|--|---|---|
| A | Bulb failure warning sensor (7/75)                           | J | Overload relay 15I (2/6)<br>(power windows/seat heater) |
| B | Seat belt reminder/key warning (2/5)<br>(USA, Canada, Korea) | K | Headlight (2/37)  |
| C | Windshield wiper intermittent relay (2/4)                    | L | Central lock (2/7)                                      |
| D | Tailgate wiper intermittent relay (2/16)                     | M | Fuel pump relay (2/23)                                  |
| E | Fuel injection (2/13)  | N | Overload relay high beam (2/50)<br>(not USA, Canada)    |
| F | Foglights, front (2/34 or 2/2 USA, Canada)                   | O | -   |
| G | Headlight flasher (2/36)                                     | P | -   |
| H | Exhaust temp. sensor (2/15) (Japan)                          | R | -   |
| I | Overdrive (2/8)  | S | -   |