

Connector at left A-post (wheel housing harness)

Black connector C2 (53-pin)
Instrument panel - left wheel housing

B200F/FT, B230FB/FD/FK/FT/G (DI)			D24/TIC	
1	Starter motor 50	BL-GN	Starter motor 50 Relay, glowplug mechanism pos. 3	BL-GN BL-GN
2	High beam, left	BL-W	High beam, left	BL-W
3	Low beam, left Beam width control	GN GN-BN	Low beam, left Beam width control	GN GN-BN
4	Horn + Windshield wiper motor pos. 1 Headlight wiper motor	Y	Horn + Windshield wiper motor pos. 1 Headlight wiper motor	Y
5	Windshield wiper motor pos. 2	GR	Windshield wiper motor pos. 2	GR
6	Windshield wiper motor pos. 3	GN-W	Windshield wiper motor pos. 3	GN-W
7	Windshield wiper motor pos. 4	OR	Windshield wiper motor pos. 4	OR
8	Front foglights	W-SB	Front foglights	W-SB
9	Control module EZK (DI) pos. 5 (not FK/FT)	BN	Relay, glowplug mechanism pos. 4 Pos. 3, connector C51 at left suspension tower	BL
10	<u>B200FT, B230FK/FT:</u> Battery + Relay, radio interference suppression pos. 4	BN	-	
11	On-board diagnostic (OBD) socket B pos. 5	GR-OR	On-board diagnostic (OBD) socket B pos. 5	GR-OR
12	On-board diagnostic (OBD) socket A pos. 3	BL-P	On-board diagnostic (OBD) socket A pos. 3	BL-P
13	Turn signal, left	GN	Turn signal, left	GN
14	Parking lights, left	W	Parking lights, left	W
15	Beam width control	GR	Beam width control	GR
16	Oil pressure sensor	SB	Oil pressure sensor	SB
17	Horn -	BL-SB	Horn -	BL-SB
18	Headlight wiper motor Windshield washer motor (not FK/FT)	BL-R	Headlight wiper motor	BL-R
19	Brake fluid level sensor	VO	Brake fluid level sensor	VO
20	Engine coolant temperature (ECT) sensor pos. 1	Y-W	Engine coolant temperature (ECT) sensor pos. 1	Y-W
21	Engine coolant temperature (ECT) sensor pos. 2	Y-SB	Engine coolant temperature (ECT) sensor pos. 2	Y-SB
22	Generator D+	R	Generator D+	R
23	On-board diagnostic (OBD) socket B pos. 6	BL-W	-	
24	Service socket	P	Service socket	P
25	On-board diagnostic (OBD) socket A pos. 2	GN-GR (GN-W)	-	
26	Ignition Control Module (ICM) pos. 3	BN-W	-	
27	Power amplifier EZK (DI) pos. 1 Ignition coil 1	R-W	Generator W	R-W
28	Ignition Control Module (ICM) pos. 6 Power amplifier EZK (DI) pos. 4 On-board diagnostic (OBD) socket A pos. 4 Converter, EGR	BL	On-board diagnostic (OBD) socket A pos. 4	BL
29	Ignition Control Module (ICM) pos. 17	Y-GR	-	
30	-		Pressure sensor, turbodiesel	Y-R
31	-		-	
32	<u>B200FT, B230FK/FT:</u> Ignition Control Module (ICM) pos. 5 Others: Washer fluid level sensor	BN R-SB	-	
33	<u>B200FT, B230FK/FT:</u> Relay, radio interference suppression pos. 2 Others: Wiper motor, tailgate	BL-Y	-	
34	Door switch	BN-SB	Door switch	BN-SB
35	Door switch	W-SB	Door switch	W-SB
36	-		-	
37	Ignition Control Module (ICM) pos. 4	GR-R	Relay, glowplug mechanism pos. 1	OR
38	Ambient temperature sensor	GN-Y	Ambient temperature sensor	GN-Y
39	Ambient temperature sensor	GN-R	Ambient temperature sensor	GN-R
40	Anti-theft alarm, connector D4 pos. 1	GR-W	Anti-theft alarm, connector D4 pos. 1	GR-W
41	Anti-theft alarm, connector D4 pos. 2	BN-P	Anti-theft alarm, connector D4 pos. 2	BN-P
42	Control module cruise control pos. 10	BN-GR	-	
43	Control module cruise control pos. 2	P-SB	-	
44	Control module cruise control pos. 7	BN-OR	-	
45	Control module cruise control pos. 11	BL-OR	-	
46	Control module cruise control pos. 6	BL-GR	-	
47	Control module cruise control pos. 4	OR-W	-	
48	Control module cruise control pos. 3	OR-SB	-	
49	Control module cruise control pos. 13	GN-OR	-	
50	Solenoid valve, pulsed secondary air injection (PAIR)	BL-BN	-	
51	Anti-theft alarm, connector D4 pos. 3	BL-GN	-	
52	-		-	
53	-		-	