


Connector at right A-post (wheel housing harness and sill harness)

B200F/FT, B230FB/FD/FK/FT/G

Connector **C3** (pos. 1-25 in 53-pin)
Instrument panel harness - right wheel
housing harness



Connector **C3** (pos. 26-53 in 53-pin)
Instrument panel harness - sill harness

1	High beam, right	R-W
2	Low beam, right	GN-W
	Beam width control	GN-BN
3	Turn signal, right	BL-GN
4	Parking light, right	GR
5	<u>B200FT, B230FK/FT:</u> Washer motor, tailgate <u>Others:</u> LH control module (MFI) pos. 30	BL-Y P-W
6	<u>B200FT, B230FK/FT:</u> LH (MFI) control module pos. 12 <u>Others (DI):</u> Ignition coil 15	GN-GR BL
7	<u>B200FT, B230FK/FT:</u> LH (MFI) control module pos. 30 <u>Others:</u> Battery + Relay, radio interference suppression pos. 2 and 4	P-W BN
8	Oxygen sensor (HO2S) heating	P
9	LH control module (MFI) pos. 9 Idle air control (IAC) valve pos. 1 Mass air flow sensor (MAF) pos. 5 Relay, radio interference suppression pos. 2 (not FK/FT) Injectors (not FK/FT) <u>B200FT, B230FK/FT:</u> PTC-resistor	BL-Y
10	LH control module (MFI) pos. 35	BL
11	LH control module (MFI) pos. 22	BN-W
12	LH control module (MFI) pos. 4	W
13	Front foglights	W-SB
14	LH control module (MFI) pos. 20	Y-SB
15	Headlight wiper motor	Y
16	Beam width control	GR
17	Headlight wiper motor <u>B200FT, B230FK/FT:</u> Washer motor	BL-R
18	LH control module (MFI) pos. 1	Y-GR
19	LH control module (MFI) pos. 28	GR-R
20	-	
21	LH control module (MFI) pos. 15	GN-Y
22	<u>B200FT, B230FK/FT:</u> LH control module (MFI) pos. 21	R
23	-	
24	<u>B200FT, B230FK/FT:</u> Washer fluid level sensor <u>Others:</u> LH control module (MFI) pos. 12	BL-W GN-W
25	LH control module (MFI) pos. 34	VO-W

26	-	
27	-	
28	-	
29	Door-open warning light, right rear	GN-R
30	Door switch rear door	BN-SB
	Door switch right front door	BN-SB
31	Door switch right front door	W-SB
32	Side turn signal repeaters	BL-GN
33	-	
34	-	
35	Loudspeaker, right rear door +	BL-P
36	Loudspeaker, right rear door -	BN-P
37	-	
38	Central locking, rear door	R-W
39	-	
40	-	
41	Central locking, rear door	BL-R
42	-	
43	-	
44	-	
45	-	
46	-	
47	-	
48	-	
49	-	
50	Power window lift motor, rear door	BN
51	Power window lift motor, rear door	Y
52	-	
53	Power window lift motor, rear door ON/OFF	P