



Connector in engine compartment at left suspension tower



B200F, B230FB/FD/G

B200FT, B230FK/FT

Connector C50 (8-pin)

Connector C50 (8-pin)

1	-		Injector 1	GN
2	Pos. 1, connector C137 at right suspension tower (4-pin)	BL-GN	Injector 2	GN
3	Pos. 2, connector C137 at right suspension tower (4-pin)	BL-R	Injector 3	GN
4	Pos. 3, connector C137 at right suspension tower (4-pin)	BL-W	Injector 4	GN
5	Pos. 4, connector C137 at right suspension tower (4-pin)	BL-Y	-	
6	Pos. 3, connector C55 at right suspension tower (4-pin)	Y-W	-	
7	Control module LH (MFI) pos. 25 via pos. 2, connector C55 at right suspension tower	Y	Control module LH (MFI) pos. 25 via pos. 2, connector C55 at right suspension tower	Y
8	-		-	

Connector C51 (8-pin)

Connector C51 (8-pin)

1	Engine coolant temperature (ECT) sensor pos. 1	Y-W	Engine coolant temperature (ECT) sensor pos. 1	Y-W
2	Oil pressure sensor	SB	Oil pressure sensor	SB
3	Ground, control module EZK pos. 20	BN-SB	Ground, ICM pos. 20	BN
4	Generator D+	R	Generator D+	R
5	Starter motor 50	BL-GN	Starter motor 50	BL-GN
6	Throttle position (TP) switch pos. 1 Pos. 8, connector C54 at right suspension tower	OR	Throttle position (TP) switch pos. 1 Pos. 8, connector C54 at right suspension tower	OR
7	Engine coolant temperature (ECT) sensor fuel/ignition (MFI/DI) system pos. 2	R-SB	Engine coolant temperature (ECT) sensor fuel/ignition (MFI/DI) system pos. 2	R-SB
8	Engine coolant temperature (ECT) sensor pos. 2	Y-SB	Engine coolant temperature (ECT) sensor pos. 2	Y-SB

Connector C132 (8-pin)

Connector C132 (8-pin)

1	Ignition coil 1	R-W	Ignition coil 1	R-W
2	<u>All:</u> Ground, power amplifier EZK (DI) <u>B230FD:</u> Ground, control module EZK (DI) pos. 14	SB	<u>All:</u> Ground, power amplifier EZK (DI) <u>B:230FK/FT:</u> Ground, ICM pos. 14	SB
3	Temp. sensor, EGR pos. 1	Y-SB	Temperature sensor EGR pos. 1	Y-SB
4	Mass air flow (MAF) sensor pos. 1	BN	-	
5	-		Ignition coil 15	BL
6	Knock sensor (KS) pos. 1	GN	Knock sensor (KS) pos. 1	GN
7	Knock sensor (KS) pos. 2	SB	Knock sensor (KS) pos. 2	SB
8	Control module LH (MFI) pos. 31 via pos. 4, connector C55 at right suspension tower (B230FD)	Y-R	-	