


Connectors in engine compartment at right suspension tower



B200FT, B230FK/FT

Connector C54 (8-pin)

1	Idle air control (IAC) valve pos. 2	R-SB
2	Solenoid coupling A/C	GN-R
3	Idle air control (IAC) valve pos. 1	BL-Y
4	Engine coolant temp. (ECT) sensor fuel/ignition (MFI/DI) system pos. 1	GR-W
5	-	
6	Ground, LH (MFI) control module pos. 17	SB
7	Throttle position (TP) switch pos. 3 from high-output system (accessory)	R-W
8	Throttle position (TP) switch pos. 1 Pos. 6, connector C51 at left suspension tower	OR

Connector C55 (8-pin)

1	High-power system (accessory) from LH (MFI) control module pos. 28	GR-R
2	EZK MFI control module pos. 8 via connector C50 pos. 7 at left suspension tower	Y
3	-	
4	-	
5	Ground, mass air flow (MAF) sensor	BN
6	-	
7	Injectors	GR
8	Ground, LH (MFI) control module	BN

Connector C154 (3-pin)

1	Low-speed pressure sensor, engine cooling fan pos. 2 Relay, engine cooling fan pos. B1	BL-SB
2	High-speed pressure sensor, engine cooling fan pos. 2 Relay, engine cooling fan pos. B2	W-SB
3	High-pressure sensor A/C pos. 2	GN-R