

Contents

<p>How to use the wiring diagrams 2</p> <p>Fuses 4</p> <p>Electrical distribution unit 6</p> <p>Ignition switch 8</p> <p>Relay location in engine compartment 8</p> <p>Relay location, electrical dist. unit 9</p> <p>Connectors 10</p> <p>Branching points 20</p> <p>Cable harnesses and branching points 34</p> <p>Ground connections 42</p>	<p>Group 37</p> <p>Diagnostics 112</p> <p>Car alarm cable harness 114</p> <p>Pre-routed wiring for towing hook 116</p>
<p>Group 38</p> <p>Bulb malfunction indicator 118</p> <p>Bulb malfunction indicator with brake monitor 120</p> <p>Seat belt reminder 122</p> <p>Seat belt reminder with ignition key warning, USA, Canada, Korea 124</p> <p>Combined instrument 126</p> <p>Outer temperature sensor 130</p>	
<p>Group 23</p> <p>LH-jetronic 2.4 multiport fuel injection system (MFI) (B 200 F, B 230 FB/FD/G) 46</p> <p>LH-jetronic 2.4 multiport fuel injection system (MFI) (B 200 FT, B 230 FKFT) 48</p>	
<p>Group 26</p> <p>Engine cooling fan 50</p>	
<p>Group 27</p> <p>Cruise control 52</p> <p>Cruise control, Japan 54</p>	
<p>Group 28</p> <p>Electronic ignition system (EI) EZ 116 K (B 200 F, B, 230 FB/FD/G) 56</p> <p>Electronic ignition system (EI) EZ 116 K (B 200 FT, B230FK/FT) 58</p>	
<p>Group 32</p> <p>Power supply and starter system 60</p>	
<p>Group 33</p> <p>Diesel pre-heating, overload sensor and EGR (D 24 TIC) 62</p>	
<p>Group 35</p> <p>High and low beam 64</p> <p>High and low beam, Nordic region, Netherlands, Belgium 66</p> <p>High and low beam, USA, Canada 68</p> <p>High and low beam, Great Britain 70</p> <p>Reduced intensity low beam (DIM-DIP) Great Britain 72</p> <p>Beam width control 74</p> <p>Parking lights, tail lights and license plate lights 76</p> <p>Parking lights, tail lights and license plate lights USA, Canada 78</p> <p>Brake lights 80</p> <p>Brake lights, USA, Canada 82</p> <p>Backup (reversing) lights 84</p> <p>Foglights 86</p> <p>Foglights, Japan 88</p> <p>Foglights, USA, Canada 90</p> <p>Glove compartment and vanity mirror lighting 92</p> <p>Interior lighting 94</p> <p>Trunk light 96</p> <p>Instrumentation and controls lighting 98</p>	
<p>Group 36</p> <p>Turn signals and hazard warning flashers 100</p> <p>Horn 102</p> <p>Headlight wash/wipe 104</p> <p>Windshield wash/wipe 106</p> <p>Tailgate wash/wipe 108</p> <p>Cigar lighter 110</p>	
<p>Group 37</p> <p>Diagnostics 112</p> <p>Car alarm cable harness 114</p> <p>Pre-routed wiring for towing hook 116</p>	
<p>Group 38</p> <p>Bulb malfunction indicator 118</p> <p>Bulb malfunction indicator with brake monitor 120</p> <p>Seat belt reminder 122</p> <p>Seat belt reminder with ignition key warning, USA, Canada, Korea 124</p> <p>Combined instrument 126</p> <p>Outer temperature sensor 130</p>	
<p>Group 39</p> <p>Radio connections, 4-door 132</p> <p>Radio connections, 5-door 134</p> <p>Radio connections, 4-door (Radio with separate amplifier) 136</p> <p>Radio connections, 5-door (Radio with separate amplifier) 138</p> <p>Radio connections, 4-door (Radio with integral amplifier) 140</p> <p>Radio connections, 5-door (Radio with integral amplifier) 142</p> <p>Radio connections, 4-door (Radio with integral amplifier) USA, Canada 144</p> <p>Radio connections, 5-door (Radio with integral amplifier) USA, Canada 146</p>	
<p>Group 43</p> <p>AW 70/71 Overdrive with kickdown inhibitor AW 71 148</p> <p>P-shift lock, automatic transmission 150</p>	
<p>Group 59</p> <p>Anti-lock braking system ABS 152</p>	
<p>Group 83</p> <p>Power window lifts 154</p> <p>Central locking 156</p> <p>Power sunroof 158</p>	
<p>Group 84</p> <p>Heated rear window 160</p> <p>Heated rear window and door mirrors with timer relay 162</p> <p>Power door mirrors 164</p>	
<p>Group 85</p> <p>Heated driver's/passenger's seat, normal output 166</p> <p>Heated driver's/passenger's seat, high output 168</p> <p>Power seat 170</p> <p>Power seat with memory 172</p>	
<p>Group 87</p> <p>Cabin fan, standard heater 174</p> <p>Manual Climate Control (MCC) 176</p> <p>Electronic Climate Control (ECC) 178</p> <p>Exhaust temperature sensor (Japan) 180</p>	
<p>Group 88</p> <p>SRS Supplemental Restraint System (airbag) 182</p> <p>SRS Supplemental Restraint System (airbag) USA, Canada 184</p>	
<p>Function diagram 186</p> <p>Comments 209</p> <p>List of components at the end of the book</p> <p>Alphabetical index at end of book</p>	

Order no. TP 3908032 (UK)
Supersedes TP 3908031

Order no. TP 3908202 (USA/CDN)
Supersedes TP 3908201

We reserve the right to make alterations to specification