

Branching points

General

For location of branching points in the car refer to section
Cable harnesses and branching points pages 34-41

13/2 (Dashboard harness)

On/Off	Color	Remarks
2/37:2 Main lighting relay	Y-W	Only USA/CDN
3/2:4 Light switch	Y-W	Only USA/CDN
16/1A:5 Radio	Y-W	Only USA/CDN

13/3 (Dashboard harness)

On/Off	Color	Remarks
2/2:3 Relay, front fog light	W-SB	Only EU/OS
3/7:6 Foglight switch (+)	W-SB	Only EU/OS
10/5:3 Left front fog light (via connector C2:3 Left wheelhousing harness-Dashboard harness)	W-SB	Only EU/OS
10/6:3 Right fog light assy. (via connector C3:13 Right wheelhousing harness-Dashboard harness)	W-SB	Only EU/OS

13/6 (Dashboard harness)

On/Off	Color	Remarks
3/5:4 Switch, Turn signal/High (main) and low beams	BL-GN	
5/1A:1 Combined instrument	BL-GN	
10/14:3 Right turn signal, front (via connector C3:3 Right wheelhousing harness-Dashboard harness)	BL-GN	
10/47:3 Lamp, right turn signal, rear (via connector C1:8 Rocker panel (door sill) harness - Dashboard harness)	BL-GN	Only 4-door
10/47:4 Right turn signal light, rear (via connector C1:8 Rocker panel (door sill) harness - Dashboard harness)	BL-GN	Only 5-door
10/16:1 Right side flasher light (via connector C3:32 Dashboard harness-Right wheelhousing harness)	BL-GN	Not USA/CDN
D2:2 Connector alarm	BL-GN	

13/9 (Left wheelhousing harness)

On/Off	Color	Remarks
31/2 Ground point left front fender (wing)	SB	
2/12:1 Relay radio interference suppressor	SB	Only B230FT/FK engine
2/14:B1 Glow plug relay	SB	Only D24TIC engine
6/2:2 Washer motor front	SB	Not B230FT/FK engine
6/4:3 Left headlight wiper motor	SB	Not USA/CDN
6/30:2 Tailgate washer motor	SB	Only 5-door
6/38:3 Actuator motor left	BN	Not USA/CDN
7/4:2 Brake fluid level sensor (-)	SB	Only B200F, B230FB/FD/G
7/5:2 Washer fluid level sensor	SB	
17/11:8 Data Link Connector DLC	SB	