

Branching points

13/91 (Tunnel harness)

On/Off		Color	Remarks
31/66	Ground point left seat lifter	SB	
3/44:4	Seat belt lock, driver seat	SB	
4/2:31	Overheating cutout, passenger seat	SB	
9/4	Heating element, back rest passenger seat (via connector C31:2 at passenger seat and connector C34:2 below passenger seat)	SB	
4/1:31	Overheating cutout driver seat	SB	
9/3	Heating element driver seat backrest (via connector C32:2 at driver seat and connector C33:2 below driver seat)	SB	

13/92 (Dashboard harness)

On/Off		Color	Remarks
11/25:2	Fuse	GN-R	Not USA/CDN
16/2:A4, A11	Amplifier	GN-R	

13/93 (Left wheelhousing harness)

4/15:1	Ignition Discharge Module (IDM) EZ-K DI system	R-W	Only USA/CDN
20/1:1	Ignition coil (via connector C132:1 Left wheelhousing harness-Engine harness)	R-W	Only USA/CDN
5/1A:13	Combined instrument (via connector C2:27 Dashboard harness-Left wheelhousing harness)	R-W	Only USA/CDN

13/95 (Power seats harness, not shown in diagram)

On/Off		Color	Remarks
11/3:2	Fuse (via connector C157:1 at CEM)	W-SB	
3/26	Controls module, driver seat (via connector C39:2 at driver seat)	W-SB	
3/27	Controls module passenger seat (via connector C40:1 at passenger seat)	W-SB	
4/29:30	Power seat control module with memory (via connector C158:1 at driver seat)	W-SB	

13/96 (Dashboard harness)

On/Off		Color	Remarks
15/1	Positive terminal block	R	Not D24TIC, USA/CDN
2/37:1	Main lighting relay	R	Not D24TIC, USA/CDN
2/50:1	Overload relay main beam	R	Not D24TIC, USA/CDN