

**Automatic low beam with ignition lock (3/1) in position II and light switch (3/2) in position 0 (can be disconnected if fuse no. 25 is removed)**

**3/5:**

	56	56b	56a	30
A	X	X	X	X
B	X	X		
C	X		X	

A = High (main) beam flash  
B = Low beam  
C = High (main) beam