



# Connector left A-post (wheel housing harness)

## Black (SB)



C2



1	2	3	4	5
6	7	8	9	10
11	12	13	14	15
16	17	18	19	20
21	22	23	24	25
26	27	28	29	
30	31	32	33	
34	35	36	37	
38	39	40	41	
42	43	44	45	
46	47	48	49	
50	51	52	53	

B6304F/G

D24TIC

1	Starter motor 50 Relay, P-shift lock	(P) (P-SB)	Starter motor 50	(BL-GN)
2	High beam left	(BL-W)	High beam left	(BL-W)
3	Low beam left Beam width control	(GN) (BN-GN)	Low beam left Beam width control	(GN) (BN-GN)
4	Windshield wiper motor pos. 1 Horn Headlight wiper motor left (not USA/CDN)	(Y)	Windshield wiper motor pos. 1 Horn Headlight wiper motor left	(Y)
5	Windshield wiper motor pos. 2	(BN)	Windshield wiper motor pos. 2	(BN)
6	Windshield wiper motor pos. 3	(GN-SB)	Windshield wiper motor pos. 3	(GN-SB)
7	Test socket B (On-board diagnostic OBD system) pos. 6	(W)	Diagnostic socket B (OBD) pos. 6	(W)
8	Fog lights, auxiliary lights	(W-SB)	Foglight, auxiliary lights	(W-SB)
9	Windshield wiper motor pos. 4	(BL)	Windshield wiper motor pos. 4	(BL)
10	Control module timing connector B pos. 10 Control module cruise control pos. 7	(Y-BN)		
11	DTC B pos. 5	(GR-OR)	Diagnostic socket B (OBD) pos. 5	(GR-OR)
12	Turn signal left	(GN)	Turn signal left	(GN)
13	Parking light left	(W)	Parking light left	(W)
14	Horn (pre-routed wiring for anti-theft alarm)	(BN-OR)	Horn (pre-routed wiring for anti-theft alarm)	(BN-OR)
15	Control module Motronic (MFI) pos. 41	(Y-GR)	Relay, glowplug pos. A:4 Fuel valve via connector C50 pos. 3	(BL-GN) (BL-GN)
16	DTC A pos. 3	(BL-P)	Relay, glowplug mechanism pos. A:1	(OR)
17	Washer motor Headlight wiper motor left (not USA/CDN)	(BL-R)	Washer motor Headlight wiper motor left	(BL-R)
18	Brake fluid level warning	(GR-W)	Brake fluid level warning	(GR-W)
19	Engine coolant temperature (ECT) sensor +	(Y-W)	Engine coolant temperature (ECT) sensor +	(Y-W)
20	Oil pressure sensor	(SB)	Oil pressure sensor	(SB)
21	Generator D+ Control module ABS pos. 15	(R) (R)	Generator D+ Control module, ABS, pos. 15	(R) (P)
22	Windshield wiper motor pos. 1	(Y)	Windshield wiper motor pos. 1	(Y)
23	Preheating heated oxygen sensor (HO2S)	(P)	Service socket 50	(P)
24	Conector C131 pos. 35	(BL-SB)		
25	Conector C131 pos. 30	(GR-SB)		
26	+15 supply controlsystem for fuel injection timing and DTC diagnosis	(BL)	DTC socket A (OBD) pos. 4	(BL)
27	Horn -	(BN-SB)	Horn	(BN-SB)
28	Beam width control (not USA/CDN)	(GR)	Beam width control	(GR)
29	Washer fluid level sensor pos. 1	(BL-W)		
30	Engine coolant temperature (ECT) sensor -	(BN-GR)	Engine coolant temperature (ECT) sensor -	(BN-GR)
31	Tailgate washer pump	(BL-Y)	Solenoid coupling A/C compressor	(GN-Y)
32	Control module, Motronic, pos. 40	(GN-Y)	Pressure monitor, turbo	(Y-R)
33	Control module, Motronic, pos. 3	(BN-P)	Generator W+	(R-W)
34	Motronic pos. 6	(R-W)	Control module, cruise control pos. 5	(VO-W)
35	Control module, cruise control pos. 5	(VO-W)	Solenoid switch, hood (pre-routed wiring for anti-theft alarm)	(GR-OR)
36	Solenoid switch, hood (pre-routed wiring anti-theft alarm)	(GR-OR)	Control module, cruise control pos. 2	(P-SB)
37	Control module Motronic (MFI) pos. 14	(GN-OR)	Hydraulic unit ABS pos. 11	(GN)
38	Control module Motronic (MFI) pos. 34	(Y-BN)	Control module ABS pos. 29	
39			Control module ABS pos. 25	
40	Splice fused + supply	(GN-R)	Control module cruise control pos. 7	(Y-BN)
41	Control module transmission connector B pos. 9	(GN-Y)	Control module ABS pos. 1	(BL-R)
42	Control module transmission connector B pos. 11	(GR-R)	Control module ABS pos. 7	(GN-W) (GN-W)
43	Control module Motronic (MFI) pos. 15	(OR)	Control module ABS pos. 9	(BN-W)
44	Control module Motronic (MFI) pos. 23	(P-W)	Control module cruise control pos. 11	(BL-OR)
45	Control module cruise control pos. 11	(BL-OR)	Control module cruise control pos. 6	(BL-GR)
46	Control module cruise control pos. 6	(BL-GR)	Control module cruise control pos. 4	(OR-W)
47	Control module cruise control pos. 4	(OR-W)	Control module cruise control pos. 3	(OR-SB)
48	Control module cruise control pos. 3	(OR-SB)	Control module cruise control pos. 13	(BL-Y)
49	Control module cruise control pos. 13	(BL-Y)	Control module Motronic (MFI) pos. 9	(GN-OR)
50	Control module Motronic (MFI) pos. 9	(GN-OR)	Control module ABS pos. 10	(SB)
51	Control module transmission connector B pos. 8	(GN-SB)	Ground connector left A-post	(Y-SB)
52	Control module transmission connector B pos. 2	(GN-W)		
53	Control module Motronic (MFI) pos. 18	(Y-R)		
	Control module transmission connector A pos. 30	(Y-R)		