



Connector left A-post (wheel housing harness) Black (SB)



B230GT			B204FT		
1	Starter motor 50	(BL-GN)	Starter motor 50	(BL-GN)	
2	High beam left	(BL-W)	High beam left	(BL-W)	
3	Low beam left	(GN)	Low beam left	(GN)	
4	Horn	(Y)	Horn	(Y)	
	Headlight wiper motor left		Headlight wiper motor left		
5	Windshield wiper motor pos. 2	(BN)	Windshield wiper motor pos. 2	(BN)	
6	Windshield wiper motor pos. 3	(GN-SB)	Windshield wiper motor pos. 3	(GN-SB)	
7	Test socket B (On-board diagnostic OBD system) pos. 6	(W)	Diagnostic socket B (OBD) pos. 6	(W)	
8	Fog lights, auxiliary lights	(W-SB)	Foglight, auxiliary lights	(W-SB)	
9	Windshield wiper motor pos. 4	(BL)	Windshield wiper motor pos. 4	(BL)	
10	Battery +	(Y-BN)	Battery + via splice	(Y-BN)	
11	Testsocket B, pos. 5	(GR-OR)	Diagnostic socket B (OBD) pos. 5	(GR-OR)	
12	Turn signal, left	(GN)	Turn signal left	(GN)	
13	Parking light left	(W)	Parking light left	(W)	
14	Horn (pre-routed wiring anti-theft alarm)	(BN-OR)	Horn (pre-routed wiring for anti-theft alarm)	(BN-OR)	
15	Control module EZK (DI) pos. 17	(Y-GR)	Control module EZK (DI) pos. 17	(Y-GR)	
16					
17	Washer motor	(BL-R)	Washer motor	(BL-R)	
	Headlight wiper motor left		Headlight wiper motor left		
18	Brake fluid level warning	(GR-W)	Brake fluid level warning	(GR-W)	
19	Engine coolant temperature (ECT) sensor +	(Y-W)	Engine coolant temperature (ECT) sensor +	(Y-W)	
20	Oil pressure sensor	(SB)	Oil pressure sensor	(SB)	
21	Generator D+	(R)	Generator D+	(R)	
	Control module ABS pos. 15	(P)	Control module, ABS, pos. 15	(P)	
22	Windshield wiper motor pos. 1	(Y)	Windshield wiper motor pos. 1	(Y)	
23	Service socket 50	(P)	Service socket 50	(P)	
24					
25	Control module EZK (DI) pos. 4	(R-SB)			
26	Control module EZK (DI) pos. 6	(BL)	Control module TCU pos. 23	(BL)	
	Power amplifier EZK (DI) pos. 4		Control module EZK pos. 6		
	Diagnostic socket (OBD) pos.4		Power stage EZK pos. 4		
			Diagnostic socket (OBD) pos.4		
			Blocking relay A/C pos. 1		
27	Horn -	(BN-SB)	Horn -	(BN-SB)	
28			Beam width control pos. 2	(GR)	
29	Relay injectors pos. 2	(BL-Y)	Relay, injectors pos. 2	(BL-Y)	
30	Engine coolant temperature (ECT) sensor -	(BN-GR)	Engine coolant temperature sensor -	(BN-GR)	
31			Control module TCU pos. 13	(VO)	
32					
33					
34	Ignition coil 1	(R-W)	Ignition coil 1	(R-W)	
35	Control module, cruise control, pos. 5	(VO-W)	Control module, cruise control pos. 5	(VO-W)	
36	Solenoid switch, hood (pre-routed wiring anti-theft alarm)	(GR-OR)	Solenoid switch, hood (pre-routed wiring for anti-theft alarm)	(GR-OR)	
37	Control module cruise control pos. 2	(P-SB)	Control module, cruise control pos. 2	(P-SB)	
38	Hydraulic unit ABS pos. 11	(GN)	Hydraulic unit ABS pos. 11	(GN)	
	Control module ABS pos. 29		Control module ABS pos. 29		
39	Control module ABS pos. 25	(Y-BN)	Control module ABS pos. 25	(Y-BN)	
	Control module cruise control pos. 7	(Y-BN)	Control module cruise control pos. 7	(Y-BN)	
40	Control module ABS pos. 4	(BL-R)	Control module ABS pos. 1	(Y-R)	
41			TCU valve pos. 1 via connector C50, pos. 8	(BL-GN)	
			EGTC sensor pos. 3 via connector C50, pos. 8		
42	Control module ABS pos. 7	(GN-W)	Control module ABS pos. 7	(GN-W) (GN-W)	
43	Control module ABS pos. 9	(BN-W)	Control module ABS pos. 9	(BN-W)	
44			Relay, engine cooling fan pos. B:2	(OR)	
			Control module TCU pos. 4		
45	Control module cruise control pos. 11	(BL-OR)	Control module cruise control pos. 11	(BL-OR)	
46	Control module cruise control pos. 6	(BL-GR)	Control module cruise control pos. 6	(BL-GR)	
47	Control module cruise control pos. 4	(OR-W)	Control module cruise control pos. 4	(OR-W)	
48	Control module cruise control pos. 3	(OR-SB)	Control module cruise control pos. 3	(OR-SB)	
49	Control module cruise control pos. 13	(GN-OR)	Control module cruise control pos. 13	(GN-OR)	
50	Control module cruise control pos. 10	(SB)	Control module cruise control pos. 10	(SB)	
	Ground connector, left A-post	(Y-SB)	Ground connector left A-post	(Y-SB)	
51	Control module EZK (DI) pos. 3	(BL-P)	Control module EZK (DI) pos. 3	(BL-P) (BL-P)	
52	Control module EZK (DI) pos. 5	(Y-BN)	Control module EZK (DI) pos. 5	(Y-BN)	
53	Diagnostic socket (OBD) pos. 2	(GN-GR)	Diagnostic socket (OBD) pos. 2	(GN-GR)	