



Connector left A-post (sill harness)



C1



1	2	3	4	5
6	7	8	9	10
11	12	13	14	15
16	17	18	19	20
21	22	23	24	25
26	27	28	29	
30	31	32	33	
34	35	36	37	
38	39	40	41	
42	43	44	45	
46	47	48	49	
50	51	52	53	

1	Number plate lighting	(W)
	Bulb failure sensor rear pos. 3	
2	Bulb failure sensor rear pos. 4	(GR)
3	Bulb failure sensor rear pos. 12	(Y-BN)
4	Heated rear window	(Y-R)
5	Central locking, tailgate	(R-W)
6	Central locking, tailgate	(BL-R)
7	Turn signal, left rear	(GN)
8	Turn signal, right rear	(BL-GN)
9		
10	Tailgate wiper	(Y-W)
11	Vehicle speed sensor (VSS)	(BN-W)
12	Vehicle speed sensor (VSS)	(GN-W)
13	Fuel level sensor +	(GR-W)
14	Bulb failure sensor, rear pos. 11	(Y-SB)
15	Delayed courtesy light	(W-SB)
16	Bulb failure sensor, rear pos. 8	(Y-GR)
17		
18	Rear fog lights	(VO-W)
19	Fuel pump	(P)
20	Backup (reversing) lights	(GR-SB)
21	Roof light, trunk (pre-routed wiring, anti-theft alarm)	(BN-GR)
22	Power antenna	(BL-R) (R-SB)
23	Power antenna	(GN-R) (GN-SB)
24	Tailgate wiper	(OR)
25	Fuel level sensor -	(BN)
26	Antenna amplifier (5-door)	(R-SB) (GN-OR)
27	Roof light ground connector	(BL-SB)
	Door switch, driver's door	
	Door switch, left rear	
28	Door switch, left front	(W-SB)
29	Door-open warning light, left front	30 + (GN-R)
	Door-open warning light, left rear	
	Interior lighting	
	Vanity mirror light, left	
30	Side turn signal repeater (not USA/CDN)	(GN)
31	Rear loudspeaker + left side	(Y-BN)
32	Rear loudspeaker - left side	(GN-BN)
33	Loudspeaker + parcel shelf, right	(Y-SB)
34	Loudspeaker - parcel shelf, right	(GN-SB)
35		
36	Ground connector, speedometer	(BN-SB)
37	Ground connector, left A-post	(SB)
38	Sensor, interior temperature	(GN)
39	Sensor, interior temperature	(GN)
40		
41		
42	Switch, power window right rear	(P)
43		
44		
45		
46		
47		
48	Central locking left rear door	(R-W)
49	Central locking left rear door	(BL-R)
50		
51		
52	Power window left rear door	(GN)
53	Power window left rear door	(GR)