

# List of components

1/1	Battery	3/52	Switch, power antenna
2/1	Headlight relay with bulb failure sensor	3/59	Beam width control
2/2	Foglight relay	3/63	Mode selector AW30-40/43
2/3	Regulator DIM-DIP	3/66	Idle air control (IAC) switch EGR
2/4	Intermittent wiper relay, windshield wipers	3/71	Gear position sensor
2/5	Relay, seat belt reminder/ignition key warning	3/78	Lock unit, tailgate
2/6	Overload relay 15I		
2/7	Central lock relay	4/1	Overheating protector, driver's seat
2/8	Overdrive relay	4/2	Overheating protector, passenger's seat
2/10	Power unit ECC	4/3	Control module, Cruise control
2/11	Relay, engine cooling fan	4/4	Rheostat
2/12	Relay injectors	4/5	Safety circuit, SRS
2/13	Relay fuel injection	4/6	Control module ECC
2/14	Relay glowplug	4/9	Sensor unit SRS
2/15	Relay exhaust temperature sensor	4/10	Control module EZ-K (DI) system
2/16	Intermittent wiper relay, tailgate wiper	4/12	Control module Motronic (MFI) system
2/23	Relay, fuel pump	4/15	Power stage EZ-K (DI) system
2/38	Timer relay exhaust gas recirculation EGR	4/16	Control module ABS
2/45	Relay P-shift lock	4/21	Control module TCU
2/46	Relay ignition coil	4/23	Control module LH-jetronic 2.4 (MFI) system
2/48	Blocking relay A/C	4/28	Control module timing
		4/29	Control module driver's seat
		4/38	Power stage Motronic 1 (MFI) system
		4/39	Power stage Motronic 2 (MFI) system
3/1	Ignition lock		
3/2	Switch, turnsignal/high-low beam	5/1	Combined instrument
3/3	High and low beam switch	5/3	Ambient temperature sensor
3/4	Cruise control operation		
3/6	Switch, hazard warning with flasher relay		
3/7	Foglight switch	6/1	Windshield wiper motor
3/8	Switch with timer relay, heated rear window/door mirrors	6/2	Washer motor, front
3/9	Brake light switch	6/3	Right headlight wiper motor
3/10	Backup (reversing) light switch	6/4	Left headlight wiper motor
3/12	Windshield wash/wipe switch	6/5	Central locking motor passenger's side front
3/13	Rear window wash/wipe switch	6/6	Central locking motor passenger's side rear
3/14	Switch, lock button	6/7	Central locking motor driver's side rear
3/15	Power window lift switch driver's door for driver's door	6/8	Central locking motor tailgate
3/16	Power window lift switch driver's door for driver's side, rear	6/9	Power window lift motor driver's door
3/17	Power window lift switch driver's door for passenger's side front	6/10	Power window lift motor driver's side rear
3/18	Power window lift switch driver's door for passenger's side rear	6/11	Power window lift motor passenger's side front
3/19	Power window lift switch driver's side rear	6/12	Power window lift motor passenger's side rear
3/20	Power window lift switch passenger's side front	6/13	Power door mirror, driver's side
3/21	Power window lift switch passenger's side rear	6/14	Power door mirror, passenger's side
3/22	Switch for rear power window lifts	6/15	Motor, power sunroof
3/23	Switch for power window lifts, driver's side	6/16	Motor driver's seat backrest
3/24	Switch for power door mirror, passenger's side	6/17	Motor up-down, front edge of driver's seat
3/25	Switch, power sunroof	6/18	Motor up-down, rear edge of driver's seat
3/26	Control module, driver's seat	6/19	Motor fore-aft driver's seat
3/27	Control module, passenger's seat	6/24	Cruise control vacuum pump
3/28	Switch for heated driver's seat	6/25	Starter motor
3/29	Switch for heated passenger's seat	6/26	Generator
3/31	Door switch driver's door	6/27	Servo motor throttle control
3/32	Door switch passenger's side front	6/28	Cabin fan motor
3/33	Door switch driver's side rear	6/29	Engine cooling fan
3/34	Door switch passenger's side rear	6/30	Wiper motor, tailgate
3/35	Door switch tailgate (5-door)	6/31	Fuel pump
3/36	Switch, glove compartment light	6/32	Tailgate wiper motor
3/37	Horn contacts	6/33-1	Fuel level sensor
3/38	Switch, brake pedal	6/33-2	Fuel primer pump
3/39	Switch, clutch pedal	6/34	Power antenna
3/40	Start inhibit switch, automatic transmission	6/35	Parking heater
3/42-1	Switch on transmission	6/36	Central locking motor driver's side front
3/42-2	Oil pressure switch, kickdown valve	6/38	Actuator, left
3/42-3	Kickdown switch	6/39	Actuator, right
3/43	Switch in gear lever		
3/44	Seat belt lock, driver's seat	7/1	Bulb failure sensor, rear
3/45	Seat belt lock, passenger's seat	7/4	Brake fluid level sensor
3/47	Parking brake switch	7/5	Washer fluid level sensor
3/50	Throttle position (TP) switch/TP sensor	7/6	Oil pressure sensor
		7/7	Engine coolant temperature (ECT) sensor
		7/9	Engine coolant temperature (ECT) sensor, ECC
		7/10	Cabin temperature sensor
		7/11	Ambient temperature sensor