

15/1	Positive terminal	C8	Connector 4-pin (accessories)
15/2	30-rail in relay unit	C9	Connector at centre console 24-pin
15/3	30-rail in fusebox	C12	Connector at relay unit, 2-pin
15/4	15I-rail in relay unit	C14	Connector at relay unit, 2-pin
15/6	Fuse-protected 30-rail in relay unit	C15	Connector at transmission, 4-pin
15/9	X-rail in relay unit	C20	Connector under gear lever carrier, 2-pin
16/1	Radio	C21	Connector left B-post, 6-pin
16/3	Loudspeaker right front door	C22	Connector at trunk, 6-pin
16/4	Loudspeaker left front door	C23	Connector at tailgate, 2-pin (5-door)
16/5	Loudspeaker right rear door	C25	Connector trunk, 2-pin
16/6	Loudspeaker left rear door	C27	Connector trunk, 1-pin
16/7	Loudspeaker instrument panel right side	C31	Connector at passenger seat, 2-pin
16/8	Loudspeaker instrument panel left side	C32	Connector at driver's seat, 2-pin
16/9	Antenna	C33	Connector under driver's seat, 2-pin
16/10	Horn 1	C34	Connector under passenger's seat, 2-pin
16/11	Horn 2	C36	Connector under passenger's seat, 2-pin
16/15	CD-changer	C37	Connector under driver's seat, 2-pin
16/17	Loudspeaker, parcel shelf left side/D-post left side	C39	Connector at driver's seat, 4-pin
16/18	Loudspeaker, parcel shelf right side/D-post right side	C40	Connector at passenger's seat, 4-pin
17/1	Service socket for starter motor operation	C41	Connector under driver's seat, 6-pin
17/8	Service socket: clamp 1, cyl. 1 (engine)	C42	Connector under driver's seat, 2-pin
17/11	OBD diagnostic socket	C50	Connector 8-pin
18/1	Bridge connector 1		Left wheel housing harness - Engine wiring harness
18/2	Bridge connector 2	C51	Connector 8-pin
19/1	Engine coolant temperature (ECT) sensor		Left wheel housing harness - Engine wiring harness
19/2	Engine speed (RPM) sensor	C54	Connector 8-pin
19/3	Speedometer		Right wheel housing harness - Engine wiring harness
19/4	Clock	C55	Connector 8-pin
19/5	Fuel level sensor		Right wheel housing harness - Engine wiring harness
20/1	Ignition coil	C57	Connector at right suspension tower, 3-pin
20/2	Distributor	C61	Connector at right A-post, 8-pin
20/3-8	Spark plugs (ignition coils)	C63	Connector at left headlight, 3-pin
20/9	Glowplugs	C64	Connector at right headlight, 3-pin
20/15	Series resistance	C71	Connector 3-pin
31/1	Ground connector right front wing		Left wheel housing harness - Engine wiring harness
31/2	Ground connector left front wing	C72	Connector driver's door, 2-pin
31/3	Ground connector body	C73	Connector passenger's door, 2-pin
31/4	Ground connector engine	C74	Connector rear door, driver's side, 2-pin
31/5	Ground connector for heated rear window (4-door)	C75	Connector rear door, passenger's side, 2-pin
31/6	Ground connector left A-post	C79	Connector driver's door, 4-pin
31/9	Ground connector at parking brake lever	C91	Connector at relay unit, 2-pin
31/10	Ground connector right A-post	C93	Connector left rear wheel housing, 4-pin
31/11	Ground connector left tail light cluster	C98	Connector at power antenna, 4-pin
31/12	Ground connector right tail light cluster	C102	Connector at relay unit, 2-pin
31/13	Ground connector in trunk	C105	Connector for bridge coupling, 2-pin
31/14	Ground connector at relay unit	C111	Connector to temperature sensor, 2-pin
31/16	Ground connector at windshield wiper motor	C121	Coupling reel, steering wheel, SRS
31/17	Ground connector at power sunroof motor	C122	Connector at trunk/tailgate, 2-pin
31/18	Ground connector at centre console	C123	Connector for bridge coupling, 2-pin
31/26	Ground connector generator	C124	Connector at left wheel housing, 2-pin
31/28	Ground connector at overdrive operating solenoid	C128	Connector at AW30-40/43, 8-pin
31/30	Ground connector, A/C solenoid coupling	C129	Connector at AW30-40/43, 8-pin
31/31	Ground connector rail in relay unit	C130	Connector at AW30-40/43, 4-pin
31/32	Ground connector on engine (power ground)	C131	Connector at left suspension tower, 53-pin
31/33	Ground connector on engine (signal ground)	C132	Connector 8-pin
31/34	Ground connector tailgate connector		Left wheel housing harness - Engine wiring harness
31/35	Ground connector, antenna	C134	Connector at left engine anchorage, 1-pin
31/42	Ground connector rail via door switch, left front	C139	Connector at gear selector, 4-pin
31/56	Ground connector gear selector sensor	C143	Connector at A-post passenger's side, 24-pin
31/57	Ground connector on engine for Motronic (power ground)	C144	Connector at A-post driver's side, 24-pin
31/64	Ground connector engine cooling fan	C145	Connector, 8-pin
C1	Connector 53-pin		Left wheel housing harness - Engine wiring harness
	Instrument panel harness - Door sill harness	C149	Connector at B-post passenger's side, 11-pin
C2	Connector 53-pin	C150	Connector at B-post driver's side, 11-pin
	Instr. panel harness - Left wheel housing harness	C151	Connector at relay unit, 2-pin
C3	Connector 53-pin	C159	Connector, 2-pin, ECC engine coolant temp. (ECT) sensor
	Instr. panel harness - Right wheel housing harness	C166	Connector at relay unit, 8-pin
C5	Connector left A-post, 2-pin	C300	Connector at firewall, 4-pin (to HO2S)
C6	Connector at relay unit, 4-pin	D2	Connector alarm, 8-pin at steering column
C7	Connector at steering column, 8-pin	D3	Connector alarm, 4-pin at steering column
		D4	Connector alarm, 2-pin in engine compartment, left front
		D5	Connector towing hook, 10-pin (not USA/CDN)
		D6	Connector ambient temperature sensor, 2-pin ahead of left front wheel
		D7	Connector ambient temperature sensor, 6-pin