


Connector in engine compartment at right suspension tower



C54

B230GT

| | | |
|---|--|--------|
| 1 | Idle air control (IAC) valve pos. 2 | (W-SB) |
| 2 | A/C compressor | (GN-R) |
| 3 | Idle air control (IAC) valve pos. 1 | (BL-Y) |
| 4 | Temperature sensor LH (MFI) pos. 1 | (GR-W) |
| 5 | | |
| 6 | Ground LH (MFI) pos. 17 (power ground) | (SB) |
| 7 | Throttle position (TP) switch pos. 3 | (R-W) |
| 8 | Throttle position (TP) switch pos. 1 to LH CM pos. 2 | (OR) |

C55

| | | |
|---|--|---------|
| 1 | Control module LH (MFI) pos. 28 from high power system (accessory) | (R-SB) |
| 2 | Control module LH (MFI) pos. 25 | (Y) |
| 3 | Control module LH (MFI) pos. 10 | (GN-W) |
| 4 | Control module LH (MFI) pos. 11 | (BL-SB) |
| 5 | Ground mass air flow (MAF) sensor pos. 1 | (BN) |
| 6 | | |
| 7 | Injectors | (GR) |
| 8 | Ground LH (MFI) pos. 5 (signal ground) | (BN) |
| | Bridge connector | |

C54

B204FT

| | | |
|---|---|---------|
| 1 | Idle air control (IAC) valve pos. 2 | (R-SB) |
| 2 | Blocking relay A/C pos. 4 | (GN-SB) |
| 3 | Idle air control (IAC) valve pos. 1 | (BL-Y) |
| 4 | Temperature sensor LH (MFI) pos.1 | (GR-W) |
| 5 | | |
| 6 | Ground LH (MFI) pos. 17 (power ground) | (SB) |
| 7 | Throttle position (TP) switch pos. 3 from high-power system (accessory) | (R-W) |
| 8 | Throttle position (TP) switch pos. 6 to LH CM pos. 2 | (OR) |

C55

| | | |
|---|--|--------|
| 1 | Control module LH (MFI) pos. 28 | (GR-R) |
| 2 | Control module LH (MFI) pos. 25 | (Y) |
| 3 | | |
| 4 | | |
| 5 | Ground mass air flow (MAF) sensor pos. 1 | (BN) |
| 6 | | |
| 7 | Injectors | (GR) |
| 8 | Ground LH (MFI) pos. 5 (signal ground) | (BN) |
| | Bridge connector | |