

Contents

How to use the wiring diagrams	2	Group 37	
Fuses	4	On-board diagnosis (OBD)	106
Ignition lock and relay unit	5	Pre-routed wiring for anti-theft alarm	108
Wiring harnesses	6	Pre-routed wiring for towing hook	110
Relay location in engine compartment	8		
Connectors	10		
Ground connections	20		
Group 23			
Motronic multiport fuel injection system (MFI) (B6304F/G)	22		
Motronic multiport fuel injection system (MFI) (B6304F)			
USA/Canada	24		
LH-jetronic 2.4 multiport fuel injection system (MFI) (B230GT)	26		
LH-jetronic 2.4 multiport fuel injection system (MFI) (B204FT)	28		
Turbo control system, TCU (B204FT)	30		
Group 26			
Engine cooling fan (B230GT)	32	Radio connections, 4-door	126
Engine cooling fan (B204FT)	34	Radio connections, 5-door	128
Engine cooling fan (B6304F/G)	36		
Group 27			
Cruise control (B230GT, B204FT and D24TIC)	38		
Cruise control (B6304F/G)	40		
Cruise control, function (schematic presentation)	42		
Group 28			
Distributor ignition (DI) system EZ116K (B230GT)	46		
Distributor ignition (DI) system EZ116K (B204FT)	48		
Group 32			
Power supply	50		
Group 33			
Starter system	52		
Starter system (B6304F/G)	54		
Diesel, preheating	56		
Overload sensor (D24TIC)	58		
Diesel with EGR	60		
Group 35			
High and low beam	62		
High and low beam USA/Canada	64		
Reduced low beam (DIM-DIP), Great Britain	66		
Beam width control	68		
Parking lights, tail lights and number plate lights, 4-door	70		
Parking lights, tail lights and number plate lights, 5-door	72		
Brake lights, 4-door	74		
Brake lights, 5-door	76		
Backup (reversing) lights	78		
Backup (reversing) lights (B6304F/G)	80		
Interior, trunk and door-open warning lights	82		
Control illumination	84		
Fog lights, Europe and Australia	86		
Fog lights, USA/Canada	88		
Fog lights, Japan, Taiwan, Saudi Arabia and Overseas	90		
Group 36			
Turn signals and hazard warning flashers	92		
Turn signals and hazard warning flashers, USA/Canada	94		
Horn	96		
Windshield wash/wipe	98		
Tailgate wash/wipe	100		
Headlight wash/wipe	102		
Cigar lighter	104		
Group 37			
Ambient temperature gauge	112		
Bulb malfunction indicator	114		
Bulb malfunction indicator with brake monitor	116		
Seat belt reminder	118		
Seat belt reminder with ignition key warning, USA, Canada and Korea	120		
Combined instrument	122		
Combined instrument B6304F/G	124		
Group 38			
M46 overdrive	130		
AW70/71 overdrive	132		
AW71 overdrive with kickdown inhibitor	134		
AW30-40/43 electronically controlled automatic transmission	136		
P-shift lock, automatic transmission	138		
Group 39			
Radio connections, 4-door	126		
Radio connections, 5-door	128		
Group 43			
ABS brake system (B230GT, 204FT and D24TIC)	140		
ABS brake system (B6304F/G)	142		
Group 59			
Power window lifts	144		
Central locking	146		
Group 83			
Heated rear window and door mirrors with timer relay	148		
Power door mirrors	150		
Group 84			
Heated driver's / passenger's seat	152		
Power seat	154		
Power seat with memory	156		
Group 85			
Electronic climate control, ECC (B230GT and D24TIC)	158		
Electronic climate control, ECC (B204FT)	160		
Electronic climate control, ECC (B6304F/G)	162		
Power sunroof	164		
Temperature sensor, Japan	166		
SRS Supplemental Restraint System (airbag)	168		
SRS Supplemental Restraint System (airbag) USA/Canada	170		
Feedback	172		
List of components (foldout)	at end of book		
Alphabetical index	at the end of the book		
Order no. TP 3905032 Supersedes: TP 3905031			
Order no. TP 3905202 (USA/CDN) Supersedes: TP 3905201			

We reserve the right to make alterations to specification