

Cruise control (B6304F/G)

Live connections in different settings of switch 3/4 with ignition switch in position II

3/4	OFF	ON	ON Set speed	RESUME
1		X	X	X
2	X	X	X	X
3				X
4			X	

Function diagram see page 42

