


Cruise control, function (schematic presentation)



Braking

Switch set to ON.
 Brake pedal pressed.

The cruise facility is disengaged when supply to 6/24 is disconnected at the same time as connector 4/3:7 no longer receives ground potential (via the brake lights).