



Overload sensor (D24TIC)



Engine running, charge pressure too high
Indicator lamp on



Engine running, coolant temperature too high
(Warning lamp lit via internal function in combined instrument)

