Bulb malfunction indicator

Indicator lamp, 10/88, lights up when a bulb fails in any of the following circuits:
- Brake light
- Low beam
- Tail light