


Connectors in engine compartment at right suspension tower



B230F, REX-I (DI)

B200FT, B230FT/GT

Connector C54 (8-pin)

Connector C54 (8-pin)

1	Idle air control (IAC) valve pos. 3	(R-SB)	Idle air control (IAC) valve pos. 2	(R-SB)
2	Solenoid coupling, A/C	(GN-R)	Solenoid coupling A/C	(GN-R)
3	-		Idle air control (IAC) valve pos. 1	(BL-Y)
4	Engine coolant temperature (ECT) sensor, fuel/ignition (MFI/DI) system pos. 1	(GR-W)	Engine coolant temp. (ECT) sensor fuel/ignition (MFI/DI) system pos. 1	(GR-W)
5	-		-	
6	Ground, Regina (MFI) control module	(SB)	Ground, LII (MFI) control module	(SB)
7	Throttle position (TP) switch pos. 3	(R-W)	Throttle position (TP) switch pos. 3 from high-output system (accessory)	(R-W)
8	Throttle position (TP) switch pos. 1 Pos. 6, connector C51 at left suspension tower	(OR)	Throttle position (TP) switch pos. 1 Pos. 6, connector C51 at left suspension tower	(OR)

Connector C55 (8-pin)

Connector C55 (8-pin)

1	-		-	
2	Control module REX-I (DI) pos. 8 via pos. 5, connector C50 at left suspension tower	(Y)	ICM pos. 8 via pos. 7, connector C50 at left suspension tower	(Y)
3	-		High-power system (accessory) from LII (MFI) control module pos. 28	(GR-R)
4	-		-	
5	Ground, Regina (MFI) control module	(SB)	Ground, mass air flow (MAF) sensor	(BN)
6	Injectors IAC pos. 1 via splice	(GN-R) (GN)	-	
7	Injectors	(GR)	Injectors	(GR)
8	Ground, Regina (MFI) control module	(BN)	Ground, LII (MFI) control module	(BN)

Connector C137 (4-pin)

1	Pressure sensor, intake manifold, air temp. sensor via pos. 8, connector C50 at left suspension tower	(BN-SB)
2	Pressure sensor, intake manifold via pos. 1, connector C50 at left suspension tower	(BL-R)
3	Pressure sensor, intake manifold via pos. 3, connector C50 at left suspension tower	(BL-SB)
4	Air temp. sensor via pos. 4, connector C50 at left suspension tower	(GN)

Connector C154 (1-pin)

1	High-pressure sensor A/C pos. 2	(GN-R)
---	---------------------------------	--------

Connector C154 (3-pin)

1	Low-speed pressure sensor, engine cooling fan Relay, engine cooling fan pos. 1B	(BL-SB)
2	High-speed pressure sensor, engine cooling fan Relay, engine cooling fan pos. 2B	(W-SB)
3	High-pressure sensor A/C pos. 2	(GN-R)