



Cruise control, function (schematic presentation)



Braking

Switch set to ON.
Brake pedal pressed down.

The brake valve breaks the supply of voltage to connection 3 and the brake light switch closes, diverting battery voltage to connection 7. This disengages the cruise control.



Resuming set speed

Switch set to RESUME.

The car resumes its previously set speed.