



31/31




Overload relay 15I (power windows/heated seats)
 Main lighting relay
 Overload relay main beam
 Combined instrument
 Beam width control
 Fog light switch
 Flasher switch
 Switch, hazard flashers
 Intermittent operation relays
 Switch, el. heated rear window/door mirrors
 Central Locking relay
 Bulb failure warning sensor
 Seatbelt reminder/key warning relay
 Overdrive relay
 Solenoid, P-shift lock
 Central locking motors
 Sunroof
 Relay, exhaust temperature sensor (Japan)
 Lighting controls
 Cigar lighter

31/12




Right tail light


31/6



ABS control module




31/66



Cruise control control module
 Combined instrument
 Seat belt lock, driver seat
 Radio
 Separate amplifier, radio
 Compact Disc changer
 Switch, heated seat
 Power seat

31/11



Left tail light
 High-level brake light
 Antenna
 Tailgate wiper motor
 Trunk lighting
 License plate light
 Fuel pump
 Courtesy light
 Reading lights
 Tow hitch
 Heated rear window