




M46 Overdrive



Engaging overdrive,
gear lever in 4th gear.



Downshift from 4th gear,
overdrive disengages
automatically.



Disengaging overdrive,
gear lever in 4th gear.

