



C144 Driver's door

C143 Passenger's side door

C149, C150 Rear door

| | | | | | | |
|----|------------------------------------|-----------------|--------------------------|------------|---------------------|--------|
| 1 | Warning light, door | (GN-R) | Warning light, door | (GN-R) | Central locking | (R-W) |
| 2 | Warning light, door | (W-SB) | Warning light, door | (W-SB) | Central locking | (BL-R) |
| 3 | Loudspeaker + | (Y-W) | Loudspeaker + | (Y-W) | Warning light, door | (GN-R) |
| 4 | Loudspeaker - | (W) | Loudspeaker - | (W) | Warning light, door | (W-SB) |
| 5 | | | Central locking | (R-W) | Power window lift | (P) |
| 6 | | | Central locking | (BL-R) | Power window lift | (BN) |
| 7 | Heated door mirror | (BL-GN) | Heated door mirror | (BL-GN) | Power window lift | (R) |
| 8 | Switch power door mirror | (BL-W) | Power door mirror | (BL-W) | Loudspeaker | (Y-W) |
| 9 | Switch power door mirror | (BN-W) | Power door mirror | (BN-W) | Loudspeaker | (W) |
| 10 | Switch power door mirror | (OR) | | | | |
| 11 | Switch power door mirror | (GN-W) | Power door mirror | (GN-W) | | |
| 12 | Switch, central locking | (BL-GN) | | | | |
| 13 | Central locking | (GN-SB) (GN-SB) | | | | |
| 14 | Central locking | (Y-SB) (Y-SB) | | | | |
| 15 | Switch power window lift | (BN) | | | | |
| 16 | Switch power window lift | (Y) | | | | |
| 17 | Switch power window lift | (GN) | | | | |
| 18 | Switch power window lift | (GR) | | | | |
| 19 | Switch power window lift | (P) | | | | |
| 20 | + supply, switch power window lift | (GR-R) | | | | |
| 21 | Ground power door mirror | (SB) | Ground power door mirror | (SB) | | |
| 22 | Switch power window lift | (BL) | Switch power window lift | (BL) | | |
| 23 | Switch power window lift | (R) (GR-R) | Switch power window lift | (R) (GR-R) | | |
| 24 | | | Switch power window lift | (GR-R) | | |