



# Connector console wiring harness - instrument panel harness



C9



|    |    |
|----|----|
| 2  | 1  |
| 4  | 3  |
| 6  | 5  |
| 8  | 7  |
| 10 | 9  |
| 12 | 11 |
| 14 | 13 |
| 16 | 15 |
| 18 | 17 |
| 20 | 19 |
| 22 | 21 |
| 24 | 23 |

C9

|    |                                    |         |
|----|------------------------------------|---------|
| 1  | Parking brake switch               | (BN-W)  |
| 2  | Lighting, seat heating switch      | (BN-SB) |
| 3  | Ashtray light                      | (Y-W)   |
|    | Lighting, seat heating switch      | (Y-W)   |
| 4  |                                    |         |
| 5  |                                    |         |
| 6  |                                    |         |
| 7  | Seat belt lock switch, left        | (GN)    |
| 8  | Seat belt lock switch, right       | (GN-W)  |
| 9  | Switch for heated driver's seat    | (Y-VO)  |
| 10 | Switch for heated passenger's seat | (Y-VO)  |
| 11 | SRS crash sensor pos. 20           | (OR-SB) |
| 12 | SRS crash sensor pos. 21           | (Y-SB)  |
| 13 | SRS crash sensor pos. 29           | (GR-OR) |
| 14 | SRS crash sensor pos. 28           | (R)     |
| 15 | Power driver's seat                | (OR)    |
|    | Heated passenger's seat            | (OR)    |
| 16 | Ground connector, centre console   | (SB)    |
| 17 | Power driver's seat                | (W)     |
|    | Power passenger's seat             | (W)     |
| 18 | Power seats + supply               | (R-SB)  |
| 19 |                                    |         |
| 20 |                                    |         |
| 21 |                                    |         |
| 22 |                                    |         |
| 23 |                                    |         |
| 24 |                                    |         |

C9 USA/CDN

|    |                                    |         |
|----|------------------------------------|---------|
| 1  | Parking brake switch               | (BN-W)  |
| 2  | Lighting, seat heating switch      | (BN-SB) |
| 3  | Ashtray light                      | (Y-W)   |
|    | Lighting, seat heating switch      | (Y-W)   |
| 4  |                                    |         |
| 5  |                                    |         |
| 6  |                                    |         |
| 7  | Seat belt lock switch, left        | (GN)    |
| 8  | Seat belt lock switch, right       | (GN-W)  |
| 9  | Switch for heated driver's seat    | (Y-VO)  |
| 10 | Switch for heated passenger's seat | (Y-VO)  |
| 11 | SRS crash sensor pos. 1            | (OR-SB) |
| 12 | SRS crash sensor pos. 15           | (Y-SB)  |
| 13 | SRS crash sensor pos. 29           | (GR-OR) |
| 14 | SRS crash sensor pos. 19           | (R)     |
| 15 | Power driver's seat                | (OR)    |
|    | Heated passenger's seat            | (OR)    |
| 16 | Ground connector, centre console   | (SB)    |
| 17 | Power driver's seat                | (W)     |
|    | Power passenger's seat             | (W)     |
| 18 | Power seats + supply               | (R-SB)  |
| 19 |                                    |         |
| 20 |                                    |         |
| 21 |                                    |         |
| 22 |                                    |         |
| 23 |                                    |         |
| 24 |                                    |         |