


# Fuses



## Fuse no. Functions

- 1 Parking light  
Number plate light
- 2 Parking light
- 3 Left high beam
- 4 Right high beam
- 5 Spare
- 6 Left low beam  
Left beam width control
- 7 Right low beam  
Right beam width control
- 8 Fog lights, front
- 9 Fog lights, rear
- 10 Instrument and control lighting
- 11 Backup (reversing) lights  
Turn signals  
Cruise control
- 12 Reduced intensity low beam (DIM-DIP)  
P-shift lock (automatic transmission)
- 13 Heated rear window  
Heated door mirrors
- 14 15-rail in relay unit  
- Bulb malfunction indicator, rear  
- Exhaust temperature sensor (Japan)  
- Overdrive  
- Key reminder (USA/CDN)  
- Anti-theft alarm (pre-routed wiring)

## Fuse no. Functions

- 14 - Power window lifts  
- Power sunroof  
- Seat belt reminder  
- Overload relay 151
- 15 Spare
- 16 Heated seats
- 17 Spare (accessories)
- 18 Radio
- 19 Climate unit ECC  
Power door mirrors  
Tailgate wash/wipe  
Ambient temperature gauge  
Power seats  
Cigar lighter
- 20 Horn
- 21 Windshield wash/wipe  
Headlight wash/wipe
- 21 Glowplug, diesel  
Mode selector (AW30-40/43)  
Fuel valve, diesel  
EGR-system, diesel  
Turbo control valve, TCU
- 22 ABS
- 23 Supply to control modules for  
- Automatic transmission AW30-40/43  
- Motronic (MFI)  
Relay, ignition coil (Motronic MFI)
- 24 Control module, Motronic (MFI)  
Control module AW30-40/43

## Fuse no. Functions

- 25 Hazard warning flashers  
Central locking  
Anti-theft alarm (pre-routed wiring)
- 26 30-rail in fuse unit  
- Clock  
- Interior lighting  
- Door-open warning lights  
- Vanity mirror light  
- Glove compartment light  
- Trunk light  
- Reading lamps  
- Anti-theft alarm (pre-routed wiring)
- 27 Brake lights  
Control module AW-30-40/43, brake signal  
P-shift lock (automatic transmission)  
Control module ABS, brake signal
- 28 Heater fan ECC  
Climate unit ECC
- 29 Power antenna  
Trailer
- 30 Fuel primer pump  
Heated oxygen sensor (HO2S)
- 31 Relay, fuel injection (MFI)  
Fuel pumps  
Distributor ignition (DI) system, EZ-116K
- 32 Spare
- 33 Radio
- 34 Power window lifts  
Power sunroof
- 35 Power seats