



# Parking lights, tail lights and number plate lights, 4-door



Ignition key in position 0.  
Light switch at parking light position.



Ignition key at II.  
Light switch at low/high beam setting.

